



Operator's Manual

NV360

V-Blade





500 Venture Drive
Orrville, OH 44667
www.ventrac.com

To the Owner Contact Information and Product Identification

If you need to contact an authorized Ventrac dealer for information on servicing your product, always provide the product model and serial numbers.

Please fill in the following information for future reference. See the picture(s) below to find the location of the identification numbers. Record them in the spaces provided.

Dealer _____ Date of Purchase: _____

Dealer Address: _____

Dealer Phone Number: _____ Dealer Fax Number: _____

With your mobile device, you can scan the QR code on the serial number plate to access manuals, warranty, and other product information.



Model # _____

Serial # _____



Venture Products Inc. reserves the right to make changes in design or specifications without obligation to make like changes on previously manufactured products.

TABLE OF CONTENTS

INTRODUCTION	PAGE 4
Product Description	4
Why Do I Need an Operator’s Manual?	4
Using Your Manual	5
Manual Glossary	5
SAFETY	PAGE 6
General Safety Procedures	6
Training Required	6
Requirements for Personal Protective Equipment (PPE)	6
Operation Safety.	6
Keep Riders Off	8
Operating On Slopes	8
Truck Or Trailer Transport	8
Maintenance	8
Fuel Safety	9
Hydraulic Safety	10
NV360 Safety Procedures.	11
Safety Decals.	12
OPERATIONAL CONTROLS	PAGE 14
Operational Control Locations	14
V-Blade Control Functions	14
GENERAL OPERATION	PAGE 15
Daily Inspection	15
Attaching	15
Detaching.	15
Operating Procedure	15
Transport of the Attachment.	16
V-blade Safety Trip.	16
Skid Shoe Adjustment.	16
SERVICE	PAGE 17
Cleaning and General Maintenance.	17
Cutting Edge Replacement	17
Skid Shoe Replacement.	17
Blade Leveling - Front to Rear	17
Lubrication Locations	18
Storage	18
Maintenance Schedule	19
Maintenance Checklist	19
SPECIFICATIONS	PAGE 20
Dimensions.	20
Features.	20

INTRODUCTION



Venture Products Inc. is pleased to provide you with your new Ventrac NV360 V-blade! We hope that Ventrac equipment will provide you with a ONE Tractor Solution.

Please visit our website, or contact your authorized Ventrac dealer for a complete list of items available for your new V-blade.

	Item Description	Part Number
Accessories	Polyurethane Cutting Edge Kit	70.8220
	6 inch Extensions with Steel Cutting Edges	70.8227
	6 inch Extensions with Polyurethane Cutting Edges	70.8228

Product Description

The NV360 V-blade is designed for the sole purpose of snow removal. The V-blade is an excellent tool for snow removal with all the capabilities of a straight blade, plus the added versatility of sweeping both wings back for single pass clearing of sidewalks or sweeping both wings forward to clear larger areas without the need for repeated cleanup passes.

Each blade wing can be angled forward or backward 30 degrees using the power unit's hydraulic control lever. The angle of each wing is controlled independently. The power unit must be equipped with a dual front hydraulic auxiliary kit.

Why Do I Need an Operator's Manual?

This manual has been created to help you gain the important knowledge of what is needed to safely operate and maintain your machine, and to avoid injury and product damage. It is divided into chapters for convenient reference of the appropriate information.

You must read and understand the operator's manual for each piece of Ventrac equipment you own. Reading the operator's manual will help you become familiar with each specific piece of equipment. If this manual becomes damaged or unreadable, it should be replaced immediately. Contact your local Ventrac dealer for a replacement.

When using a Ventrac attachment, be sure to read and follow the safety and operating instructions of both the power unit and the attachment being used to ensure the safest operation possible.

The information in this manual provides the operator with the safest procedures to operate the machine while getting the maximum use out of the unit. Failure to follow the safety precautions listed in this manual may result in personal injury and/or damage to the equipment.

INTRODUCTION

Using Your Manual

This manual identifies potential hazards and safety concerns to help you, as well as others, avoid personal injury and/or damage to the equipment.

Safety should always be the first priority when working on or operating equipment. Accidents are more likely to occur when proper operating procedures are not followed or inexperienced operators are involved.

SYMBOL DEFINITIONS



This symbol identifies potential health and safety hazards. It marks safety precautions. Your safety and the safety of others is involved.

There are three signal words that describe the level of safety concern: Danger, Warning, and Caution.

SIGNAL WORD DEFINITIONS

DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This signal word is limited to the most extreme cases.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and/or property damage. It may also be used to alert against unsafe practices.

This manual also uses two words to highlight information. **ATTENTION** calls attention to special mechanical information to prevent equipment damage and/or best practices for equipment service and care.

NOTE emphasizes general information that is worthy of special attention.

NOTE: Right-Hand and Left-Hand orientations may be referred to at different places throughout this manual. Right-Hand and Left-Hand is determined as if facing forward from the operator station.

Manual Glossary

- Power Unit** A Ventrac tractor or other Ventrac engine powered device that may be operated by itself or with an attachment or accessory.
- Attachment** A piece of Ventrac equipment that requires a Power Unit for operation.
- Accessory** A device that attaches to a Power Unit or Attachment to extend its capabilities.
- Machine** Describes any "Attachment" or "Accessory" that is used in conjunction with a power unit.

SAFETY



General Safety Procedures for Ventrac SSV Power Units, Attachments, & Accessories



Training Required

- The owner of this machine is solely responsible for properly training the operators.
- The owner/operator is solely responsible for the operation of this machine and for the prevention of accidents or injuries occurring to him/herself, other people, or property.
- Do not allow operation or service by children or untrained personnel. Local regulations may restrict the age of the operator.
- Before operating this machine, read the operator's manual and understand its contents.
- If the operator of the machine cannot understand this manual, then it is the responsibility of this machine's owner to fully explain the material within this manual to the operator.
- Learn and understand the use of all the controls.
- Know how to stop the power unit and the attachments quickly in the event of an emergency.

Requirements for Personal Protective Equipment (PPE)

- The owner is responsible for ensuring that all the operators use the proper PPE while operating the machine. Whenever you use the machine, use the following PPE:
- Certified eye protection and hearing protection.
- Closed toe, slip resistant footwear.
- Long pants or trousers.
- A dust mask for dusty conditions.
- Appropriate cold weather clothing.
- Additional PPE may be required. Refer to the product safety procedures for any additional requirements.

Operation Safety

- Secure long hair and loose clothing. Do not wear jewelry.
- Inspect the machine before operation. Repair or replace any damaged, worn, or missing parts. Be sure the guards and shields are in proper working condition and are secured in place. Make any necessary adjustments before operating the machine.
- Some pictures in this manual may show shields or covers opened or removed in order to clearly illustrate the instructions. Under no circumstance should the machine be operated without these devices in place.
- Alterations or modifications to this machine can reduce safety and could cause damage to the machine. Do not alter the safety devices or operate with the shields or covers removed.
- Before each use, verify that all the controls function properly and inspect all the safety devices. Do not operate if the controls or safety devices are not in proper working condition.
- Check the parking brake function before operating. Repair or adjust the parking brake if necessary.
- Observe and follow all of the safety decals.
- All the controls are to be operated from the operator's station only.
- Ensure the attachment or accessory is locked or fastened securely to the power unit before operating.
- Ensure that all bystanders are clear of the power unit and the attachment before operating. Stop the machine if someone enters your work area.
- Always be alert to what is happening around you, but do not lose focus on the task you are performing. Always look in the direction the machine is moving.

SAFETY



General Safety Procedures for Ventrac Power Units, Attachments, & Accessories



- Look behind and down before backing up to be sure of a clear path.
- If you hit an object, stop and inspect the machine. Make any necessary repairs before operating the machine again.
- Stop operation immediately at any sign of equipment failure. An unusual noise can be a warning of equipment failure or a sign that maintenance is required. Make any necessary repairs before operating the machine again.
- Do not leave the machine unattended while it is running.
- Always park the machine on level ground.
- Always shut off the engine when connecting the attachment drive belt to the power unit.
- Never leave the operator's station without lowering the attachment to the ground, engaging the parking brake, shutting off the engine, and removing the ignition key. Make sure all moving parts have come to a complete stop before dismounting.
- Never leave the machine unattended without lowering the attachment to the ground, engaging the parking brake, shutting off the engine, and removing the ignition key.
- Only operate in well-lit conditions.
- Do not operate when there is a risk of lightning.
- Never direct the discharge of any attachment in the direction of people, buildings, animals, vehicles, or other objects of value.
- Never discharge material against a wall or obstruction. The material may ricochet back toward the operator.
- Use extra caution when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Do not run the engine in a building without adequate ventilation.
- Do not touch the engine or the muffler while the engine is running or immediately after stopping the engine. These areas may be hot enough to cause a burn.
- Do not change the engine governor settings or over-speed the engine. Operating the engine at excessive speeds may increase the hazard of personal injury.
- To reduce the hazard of fire, keep the battery compartment, engine, and muffler areas free of grass, leaves, excessive grease, and other flammable materials.
- Clear the working area of objects that might be hit or thrown from the machine.
- Keep people and pets out of the working area.
- Know the work area well before operation. Do not operate where traction or stability is questionable.
- Reduce speed when you are operating over rough ground.
- Equipment can cause serious injury and/or death when improperly used. Before operating, know and understand the operation and safety of the power unit and the attachment being used.
- Do not operate the machine if you are not in good physical and mental health, if you will be distracted by personal devices, or if you are under the influence of any substance which might impair your decisions, dexterity, or judgment.
- Children are attracted to machine activity. Be aware of children and do not allow them in the work area. Turn off the machine if a child enters the work area.
- Power units, attachments, and accessories are not designed or intended for travel on public roadways. Never operate or travel on public roads or highways.

SAFETY



General Safety Procedures for Ventrac Power Units, Attachments, & Accessories



- Operate with safety lights when operating near roadways.
- Slow down and be careful of traffic when operating near or crossing roadways. Stop before crossing roads or sidewalks. Use care when approaching areas or objects that may obscure vision.

Keep Riders Off

- Only allow the operator on the power unit. Keep riders off.
- Never allow riders on any attachment or accessory.

Operating On Slopes

- Slopes can cause loss-of-control and tip-over accidents, which can result in severe injury or death. Be familiar with the emergency parking brake, along with the power unit controls and their functions.
- Do not operate on slopes greater than 10 degrees.
- Do not stop or start suddenly when operating on slopes.
- Variables such as wet surfaces and loose ground will reduce the degree of safety. Do not drive where the machine could lose traction or tip over.
- Keep alert for hidden hazards in the terrain.
- Stay away from drop-offs, ditches, and embankments.
- Sharp turns should be avoided when operating on slopes.
- Transport the machine with the attachment lowered or close to the ground to improve stability.
- While operating on slopes, drive in an up and down direction whenever possible. If turning is necessary while driving across slopes, reduce your speed and turn slowly in the downhill direction.

Truck Or Trailer Transport

- Use care when loading or unloading the machine into a truck or trailer.
- Use full width ramps for loading the machine into a truck or trailer.
- The parking brake is not sufficient to lock the machine during transport. Always secure the power unit and/or attachment to the transporting vehicle securely using straps, chains, cables, or ropes. Both the front and rear straps should be directed down and outward from the machine.
- Shut off the fuel supply to the power unit during transport on a truck or trailer.
- Turn the battery disconnect switch to the Off position to shut off electrical power.

Maintenance

- Keep the safety decals legible. Remove all grease, dirt, and debris from the safety decals and instructional labels.
- If any decals are faded, illegible, or missing, contact your dealer promptly for replacements.
- When new components are installed, be sure that the current safety decals are affixed to the replacement components.
- If any component requires replacement, use only original Ventrac replacement parts.
- Always turn the battery disconnect to the Off position or disconnect the battery before performing any repairs. Disconnect the negative terminal first and the positive terminal last. Reconnect the positive terminal first and the negative terminal last.
- Keep all bolts, nuts, screws, and other fasteners properly tightened.

SAFETY



General Safety Procedures for Ventrac Power Units, Attachments, & Accessories



- Always lower the attachment to the ground, engage the parking brake, shut off the engine, and remove the ignition key. Make sure all moving parts have come to a complete stop before cleaning, inspecting, adjusting, or repairing.
- If the power unit, attachment, or accessory requires repairs or adjustments not instructed in the operator's manual, the power unit, attachment, or accessory must be taken to an authorized Ventrac dealer for service.
- Never perform maintenance on the power unit and/or attachment if someone is in the operator's station.
- Always use protective glasses when handling the battery.
- Check the fuel lines for tightness and wear on a regular basis. Tighten or repair them as needed.
- To reduce the hazard of fire, keep the battery compartment, engine, and muffler areas free of grass, leaves, and excess grease.
- Do not touch the engine, the muffler, or other exhaust components while the engine is running or immediately after stopping the engine. These areas may be hot enough to cause a burn.
- Allow the engine to cool before storing and do not store near an open flame.
- Do not change the engine governor settings or over-speed the engine. Operating engine at excessive speeds may increase the hazard of personal injury.
- Springs may contain stored energy. Use caution when disengaging or removing springs and/or spring loaded components.
- An obstruction or blockage in a drive system or moving/rotating parts may cause a buildup of stored energy. When the obstruction or blockage is removed, the drive system or moving/rotating parts may move suddenly. Do not attempt to remove an obstruction or blockage with your hands. Keep your hands, feet, and clothing away from all power-driven parts.

Fuel Safety

- To avoid personal injury or property damage, use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive.
- Do not refuel the machine while smoking or at a location near flames or sparks.
- Always refuel the machine outdoors.
- Do not store the machine or fuel container indoors where the fumes or fuel can reach an open flame, spark, or pilot light.
- Only store fuel in an approved container. Keep out of the reach of children.
- Never fill containers inside a vehicle or on a truck or trailer bed with a plastic liner. Always place the containers on the ground away from your vehicle before filling.
- Remove the machine from the truck or trailer and refuel it on the ground. If this is not possible, refuel the machine using a portable container, rather than from a fuel dispenser nozzle.
- Never remove the fuel cap or add fuel with the engine running. Allow the engine to cool before refueling.
- Never remove the fuel cap while on a slope. Only remove the fuel cap when parked on a level surface.
- Replace the fuel tank cap and the container cap securely.
- Do not overfill the fuel tank. Only fill to the bottom of the fuel neck, do not fill the fuel neck full. Overfilling of the fuel tank could result in engine flooding, fuel leakage from the tank, and/or damage to the emissions control system.

SAFETY



General Safety Procedures for Ventrac Power Units, Attachments, & Accessories



- If fuel is spilled, do not attempt to start the engine. Move the power unit away from the fuel spill and avoid creating any source of ignition until the fuel vapors have dissipated.
- If the fuel tank must be drained, it should be drained outdoors into an approved container.
- Check the fuel lines for tightness and wear on a regular basis. Tighten or repair them as needed.
- The fuel system is equipped with a shut-off valve. Shut off the fuel when transporting the machine to and from the job, when parking the machine indoors, or when servicing the fuel system.

Hydraulic Safety

- Make sure the hydraulic connections are tight and all hydraulic hoses and tubes are in good condition. Repair any leaks and replace any damaged or deteriorated hoses or tubes before starting the machine.
- Hydraulic leaks can occur under high pressure. Hydraulic leaks require special care and attention.
- Use a piece of cardboard and a magnifying glass to locate suspected hydraulic leaks.
- Keep your body and hands away from pinhole leaks or nozzles that eject high pressure hydraulic fluid. Hydraulic fluid escaping under high pressure can penetrate the skin causing serious injury, leading to severe complications and/or secondary infections if left untreated. If hydraulic fluid is injected into the skin, seek immediate medical attention no matter how minor the injury appears.
- The hydraulic system may contain stored energy. Before performing maintenance or repairs on the hydraulic system, remove any attachments, engage the parking brake, disengage the weight transfer system (if equipped), shut off the engine, and remove the ignition key. To relieve pressure on the auxiliary hydraulic system, shut off the power unit engine and move the hydraulic control lever left and right before disconnecting the auxiliary hydraulic quick couplers.

SAFETY



NV360 Safety Procedures



- Always block up the V-blade securely when adjusting the skid shoes.
- Operators should be familiar with the area they are clearing and make preparations ahead of time. Place guide stakes appropriately and remove stones, markers, or other debris that may be hidden after a snowfall. Curbs, offsets, steps, man hole covers, broken or raised pavement, etc. should be noted. Operators should map areas to be cleared before the winter season so they can review potential hazards prior to clearing snow in the area.
- If an area to be cleared is unfamiliar to the operator, travel slowly and use EXTREME CAUTION. Inquire of anyone who might know of potential hazards.
- Never travel at speeds that would cause injury to the operator or damage to the machine if the machine were to be stopped suddenly by an unseen, immovable object.
- Ensure there are no objects between the back of the blade wings and the hitch frame. When wings are angled to the swept back position, objects may be pinched or crushed between the blade wing and the hitch frame.
- Do not change the blade angle while driving. Stop the power unit before making blade wing angle adjustments.
- Do not proceed if visibility is poor. If the power unit is equipped with a windscreen, the windshield must be kept clean.
- Use caution when operating around objects that can obstruct your vision.
- The attachment hydraulic system may contain stored energy. Before performing maintenance or repairs on the hydraulic system, the attachment's auxiliary hydraulic hoses must be disconnected from the power unit. Lower the attachment to the ground and shut off power unit engine. Turn the key to the On position and move the hydraulic control lever left and right to relieve auxiliary hydraulic pressure on the first circuit. Hold the switch on the hydraulic control lever and move the hydraulic control lever left and right to relieve auxiliary hydraulic pressure on the second circuit. Turn the key to the Off position and disconnect the auxiliary hydraulic quick couplers from the power unit.


SAFETY

Safety Decals

The following safety decals must be maintained on your attachment.

Keep all safety decals legible. Remove all grease, dirt, and debris from safety decals and instructional labels. If any decals are faded, illegible, or missing, contact your dealer promptly for replacements.


When new components are installed, be sure that current safety decals are affixed to the replacement components.




SAFETY




1. Caution - pinch point. Stay away from moving parts.



1. Read the operator's manual.



1. Pinching or crushing hazard.




1. Keep your body and hands away from suspected hydraulic leaks.
2. Wear eye protection when inspecting the hydraulic system for leaks.

Decal	Description	Part Number	Quantity
A	Warning, Pinch Point	00.0364	2
B	Read Operator's Manual	00.0619	1
C	Pinching or Crushing Hazard	00.0620	2
D	High Pressure Fluid Hazard	00.0621	1

OPERATIONAL CONTROLS

Operational Control Locations

Use the following images to help identify the locations of operational controls. The letter next to each control can be referenced to the list that follows these images.



- A. Hydraulic Control Lever
- B. Dual Hydraulic Auxiliary Switch

V-Blade Control Functions

The hydraulic control lever* (A) on the power unit controls the functions of the V-blade.

Push forward on the hydraulic control lever to lower the V-blade to the ground. To place in the float position, continue pushing the lever forward until the detent engages. Pull back on the hydraulic control lever to raise the V-blade.


Move the hydraulic control lever to the right to rotate the selected blade wing back. Move the hydraulic control lever to the left to rotate the selected blade wing forward.

The dual hydraulic auxiliary switch (B) controls the blade wing selection. By default, the hydraulic control lever angles the right blade wing. Press and hold the dual hydraulic auxiliary switch to control the left blade wing angle using the hydraulic control lever.

WARNING

Angling the blade wings to the swept back position creates a pinching or crushing hazard between the blade wing and the hitch frame.

Ensure the area is clear before angling the blade wing to the rear.



The blade wings can be angled independently from 30° forward to 30° backward. Angle the blade wings to the right or left to push snow to that side. Sweep the blade wings back to push snow to both sides. Sweep the blade wings forward to clear areas without the need for repeated cleanup passes.

*Refer to power unit operator's manual for operation of power unit controls.

GENERAL OPERATION

Daily Inspection

WARNING

Always engage the parking brake, shut off the power unit engine, remove the ignition key, and ensure that all moving parts have come to a complete stop before inspecting the components, or attempting any repair or adjustment.

1. Park the machine on a level surface, with the engine shut off and all fluids cold.
2. Perform a visual inspection of both the power unit and the attachment. Look for loose or missing hardware, damaged components, or signs of wear.
3. Inspect the hydraulic hoses and the hydraulic fittings to ensure tight, leak free connections.
4. Inspect the cutting edge and skid shoes for wear and service as required.

Attaching

1. Align the power unit squarely with the V-blade. Lower the power unit front hitch until the hitch tabs are below the top plate on the hitch frame.
2. Drive forward slowly until the power unit hitch tabs are aligned with the hitch point slots in the hitch frame. Raise the power unit hitch to engage the tabs in the frame plate. Continue to raise the hitch until the V-blade is lifted off the ground.
3. Engage the parking brake* and shut off the engine.
4. Rotate the attachment latch handle* forward to the latched position. Make sure the latch tabs are engaged in the lower latch plates and the latch handle lock is engaged to prevent accidental disengagement of the latch handle.
5. Wipe hose ends clean, and connect to the power unit's hydraulic quick couplers. Connect the hoses and quick couplers so the colored indicators are paired together (red to red, etc.).

Detaching

1. Park the power unit on a level surface and set the parking brake.*
2. Adjust the blade wings to the swept back position.
3. Lower the V-blade to the ground.
4. Shut off the power unit engine.
5. Turn the power unit key to the On position.
6. Move the hydraulic control lever to the left and right, then press the switch on the control lever and move to the left and right again to release the pressure from the auxiliary hydraulic circuits.
7. Turn the power unit key to the Off position.

8. Disconnect the hydraulic quick couplers from the power unit and store the hose ends in the holes in the top plate of the hitch frame.
9. Disengage the latch handle lock* and rotate the attachment latch handle* back to unlatch from the lower hitch point on the V-blade.
10. Restart the power unit and lower the front hitch to clear the top plate on the hitch frame while slowly backing the power unit away from the V-blade.

Operating Procedure

Before operation, perform the daily inspection and verify the skid shoes are set at the desired height.

Set the weight transfer (if equipped) to the Off position.

Use the power unit's hydraulic control lever and switch to set the blade wings to the desired position or angle.

Move the machine into position and lower the V-blade to the ground. Place the power unit's hydraulic control lever in the float position by pushing it forward until the detent engages. The lever will stay in this position until intentionally removed.

When cleaning hard packed snow from hard surfaces, slight down pressure on the V-blade may be used.

Push the hydraulic control lever forward until there is slight down pressure on the V-blade and then release.

Drive forward slowly while keeping a close watch for potential hazards.

WARNING

Sudden deceleration caused by a large amount of snow or hidden objects could cause bodily injury and/or damage to the machine.

Do not push or ram materials at high speeds.

Do not change the blade angle while driving. Stop the power unit before making blade wing angle adjustments.

*Refer to power unit operator's manual for operation of power unit controls.

GENERAL OPERATION

Transport of the Attachment

Transport the V-blade in the raised position to reduce wear of the machine and to prevent the V-blade from catching on curbs or other obstacles. Travel slowly over rough or slippery surfaces in order to maintain control of the power unit.

V-blade Safety Trip

The V-blade is equipped with a safety trip feature that allows the cutting edge to rotate back or slide away from an obstacle.

⚠ WARNING

When the V-blade safety trip is activated, it may suddenly return to the operating position causing personal injury from pinching.

When the safety trip feature is activated, do not leave the operator's platform or attempt to manually reset the cutting edge.

When the safety trip is activated, it will reset itself unless it is caught on an obstacle. Do not raise the V-blade. Back slowly away from the obstacle to allow the cutting edge to return to the operating position.

Skid Shoe Adjustment

Skid shoes are provided to keep the cutting edge off the surface being cleared, especially when clearing snow from gravel driveways or walkways.

The skid shoe height is determined by the placement of spacer washers between the skid shoe and the skid shoe mount. Extra spacer washers are stored on top of the skid shoe mount.

1. Park the power unit and V-blade on a level surface and engage the parking brake.
2. Determine the number of spacer washers that need to be moved to reach the desired skid shoe height.


⚠ WARNING

Hydraulic drift or accidental release of hydraulic pressure could cause the V-blade to lower and trap a person or appendage.

Use blocks or jack stands to securely support the V-blade when adjusting the skid shoes.

3. Raise the V-blade to the highest position and adjust the blade wings so they are swept forward. Support the V-blade securely with blocks or jack stands.

4. Shut off the power unit engine and remove the ignition key.



5. Remove the linch pin (A) and the spacer washers (B) from the top of the skid shoe mount.
6. Remove the skid shoe from the bottom of the skid shoe mount. Add or remove spacer washers to reach the desired skid shoe height.
7. Insert the skid shoe back into the skid shoe mount, place any extra spacer washers on top of the skid shoe mount, and fasten the skid shoe in place with the linch pin. Both the left and right skid shoes should be set at the same height.
8. Remove the blocks or jack stands and lower the V-blade to the ground.

SERVICE

⚠ WARNING

Always engage the parking brake, shut off the power unit engine, remove the ignition key, and ensure that all moving parts have come to a complete stop before inspecting the components, or attempting any repair or adjustment.

ATTENTION

If any component requires replacement, use only original Ventrac replacement parts.

Cleaning and General Maintenance

For best results, and to maintain the finish of the V-blade, clean or wash the V-blade to remove dirt, salt deposits, and snow or ice accumulations.

ATTENTION

To maintain the finish of the power unit and attachment, thoroughly wash the equipment after each use to remove any corrosive agents (e.g., salt). Failure to clean the equipment may result in corrosion of (including but not limited to) steel, aluminum, and electrical components. Equipment that will experience repeated exposure to corrosive agents should be pretreated with a corrosion preventative.

Cutting Edge Replacement


Replace the cutting edges when they wear down near the blade frame structure. Replace all the cutting edges at the same time.

Skid Shoe Replacement

Replace the skid shoes when the wear surface is less than 3 mm (1/8 inch) thick.

Blade Leveling - Front to Rear

1. Park the power unit and V-blade on a level surface and adjust both blade wings to the swept back position.
2. Set the weight transfer (if equipped) to the Off position.
3. Lower the V-blade to the ground and place the hydraulic control lever in the float position.
4. Engage the parking brake, shut off the power unit engine, and remove the ignition key.
5. Check to see if the cutting edges are making even contact with the ground.
6. If the cutting edges are not making even contact with the ground, loosen the four bolts (A) that fasten the pivot link mounting plate to the hitch frame.



7. Slide the pivot link mounting plate forward or backward until the cutting edges make even contact with the ground.
8. Tighten the four bolts to 102 Nm (75 ft-lbs).

SERVICE


Lubrication Locations

Lubrication is required at the following locations using a lithium complex NLGI #2 grease.


Wipe the grease fittings clean before applying grease to the grease fittings.

Refer to the maintenance schedule for service intervals and the amount of grease.


Adjust the blade wings to the swept forward position. Grease the upper pivot link.




Grease the left wing cylinder, blade trip, and slides.



Grease the right wing cylinder, blade trip and slides, and the lower pivot link.



Adjust the blade wings to the swept back position and detach the V-blade from the power unit. Grease the wing blade cylinder ends.



Storage

Preparing the Attachment for Storage

1. Clean the V-blade.
2. Inspect for loose or missing hardware, damaged components, or signs of wear. Repair or replace any damaged or worn components.
3. Inspect the hydraulic hoses and the hydraulic fittings to ensure tight, leak free connections.
4. Inspect the cutting edges and skid shoes for wear and replace if necessary.
5. Inspect the safety decals. Replace any decals that are faded, illegible, or missing.
6. Apply grease to all grease points and wipe off any excess grease.
7. Inspect the painted components for chips, scratches, or rust. Clean and touch up the surfaces as needed.

Removing the Attachment from Storage

1. Clean the attachment to remove any accumulated dust or debris.
2. Inspect the attachment as instructed in the Daily Inspection section of this manual.
3. Test the attachment to ensure that all the components are working properly.

SERVICE

Maintenance Schedule

	# of locations	# of pumps	As Needed	Daily	At 50 hours	At 100 hours	At 150 hours	At 200 hours	At 250 hours	At 300 hours	At 350 hours	At 400 hours	At 450 hours	At 500 hours	At 550 hours	At 600 hours	At 650 hours	At 700 hours	At 750 hours	At 800 hours	At 850 hours	At 900 hours	At 950 hours	At 1,000 hours	Yearly
Grease and Lubrication: See Lubrication Section																									
Cylinder Ends	4	^	**		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Upper Pivot Link	2	^	**		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Lower Frame Pivot	1	^	**		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Blade Trip Pivots	2	^	**		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Blade Slide Shafts	4	^	**		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Inspection																									
Inspect for Loose, Missing, or Worn Components				✓																					
Inspect the Cutting Edges and Skid Shoes				✓																					
Inspect the Hydraulic Hoses and Fittings				✓																					
Inspect the Safety Decals				✓																					
^Grease until fresh grease is visible.																									
**Operation in severe conditions may require more frequent service intervals.																									

Maintenance Checklist

	# of locations	# of pumps	As Needed	Daily	At 50 hours	At 100 hours	At 150 hours	At 200 hours	At 250 hours	At 300 hours	At 350 hours	At 400 hours	At 450 hours	At 500 hours	At 550 hours	At 600 hours	At 650 hours	At 700 hours	At 750 hours	At 800 hours	At 850 hours	At 900 hours	At 950 hours	At 1,000 hours	Yearly
Grease and Lubrication: See Lubrication Section																									
Cylinder Ends	4	^	**																						
Upper Pivot Link	2	^	**																						
Lower Frame Pivot	1	^	**																						
Blade Trip Pivots	2	^	**																						
Blade Slide Shafts	4	^	**																						
Inspection																									
Inspect for Loose, Missing, or Worn Components																									
Inspect the Cutting Edges and Skid Shoes																									
Inspect the Hydraulic Hoses and Fittings																									
Inspect the Safety Decals																									
^Grease until fresh grease is visible.																									
**Operation in severe conditions may require more frequent service intervals.																									

SPECIFICATIONS

Dimensions

Overall Height	54.6 cm (21-1/2 inches)
Overall Length	61 cm (24 inches)
Overall Width	91.4 cm (36 inches)
Overall Width (Wings Swept Back)	91.4 cm (36 inches)
Overall Width (Wings Swept Forward)	81.3 cm (32 inches)
Weight	115.6 kg (255 pounds)
Blade Wing Angle - Forward and Backward	30 degrees

Features

- Independent left and right blade movement is controlled by separate cylinders.
- Adjustable skid shoes.
- Spring controlled cutting edge safety trip mechanism.